



Originators of

Ask The Plant
DYNAMIC CROP NUTRITION.
Your Crop's Dieticians®

4915 West Monte Cristo Road
Edinburg, Texas 78541
Telephone: 956-383-0739
Facsimile: 956-383-0730
TPSLab.com
AskThePlant.com

WATER SAMPLING

Minimum Volumes of Samples -

16 ounces (about One Litre) for most tests.

40 ounces (about Two Litres) for tests requiring biological assays (*Domestic – Aquaculture – Hydroponic – Aquaponic Suitability*) and tests involving Alkalinity.

Containers –

For non-biological tests a clean plastic water or soda bottle may be used. Be sure that it has been thoroughly washed and clean before filling. Tightly cap the bottle and pack it securely in the shipping container.

For biological tests – A sterile container must be used! A readily-available container can be a new, unused bottled water bottle. Empty out the original contents, **taking care not to touch the inside of the cap or the inside of the neck of the bottle.**

Ship **OVERNIGHT for delivery to the lab Monday through Thursday** in an insulated container with ice. Do not allow the sample to freeze.

Special Circumstance Sampling Procedures –

Irrigation Systems – Take sample from an active system that is free of stagnant water and representative of the water being actually applied to the soil.

Pond or Lake – Samples should be taken from several depths and locations, if possible. These are to be combined into one composite sample to be sent to the lab for analysis.

Deep Well or Lake – If deeper than 100 feet, **Boron** testing is recommended, as Boron generally concentrates in deeper waters.

It is recommended that a container no larger than a quart should be used, due to possible breakage or leakage during shipment. **Tightly cap and secure containers!**



**What's In
Your Water**
Becomes Part
Of Your Soil®